




Dante Controller

User Guide

For Dante Controller version 3.2.x for Windows and Mac OS X

For Windows XP and Windows 7, and Mac OS X 10.6 and 10.7



Document version: 1.0

Document name: AUD-MAN-DanteController-3.2.x-v1.0.pdf

Published: Tuesday, 15 May 2012



Contents

About Audinate	8
About Dante	8
Introduction	9
About Dante Controller	9
What's New in version 3.2	9
Before You Install: Important Notes	10
Platforms Supported	10
Minimum System Requirements	10
General	10
Windows	10
Mac OSX	10
Operating System Updates	11
Ensure Bonjour is installed	11
Firewall Configuration	11
Installing Dante Controller	12
Pre-install Checklist	12
Uninstalling Previous Versions	12
Windows	12
Mac OSX	12
Downloading Dante Controller	12
Installing Dante Controller on Windows	13
Installing Dante Controller on Mac OSX	13
Dante Basics	15
Discovery and auto-configuration	15
Automatic network configuration	15
Automatic discovery	15
Differentiating between input and output channels	15
Device and Channel Labeling	15
Rules for Labels	16
Routing Audio	16
Routing Terminology	16
Subscription	17
Redundancy	17
Audio Formats	18
Flows	18
Advanced Routing: Using Multicast	19
Clock Synchronization	19
Dante Clock Types	19
Clock Settings	19
Slave to External Word Clock	19

Preferred Master.....	19
Clocking and Synchronization in Redundant Networks.....	20
Latency.....	20
Latency and the Dante Virtual Soundcard.....	20
Dante Control and Monitoring.....	20
Starting Dante Controller.....	21
Where to find the Dante Controller application.....	21
Windows.....	21
Mac OSX.....	21
Configuring Dante Controller.....	21
Network Interface Selection.....	21
Using Dante Controller.....	23
Network View.....	23
Network View Menu bar.....	24
File.....	24
Device.....	24
Help.....	24
Network View Toolbar.....	24
Network View Tabs.....	24
Sub-views within the Network View.....	25
Routing View.....	25
Expanding the Routing View.....	25
Customizing the Network View.....	26
Device Channels.....	26
Device Status View.....	26
Clock Status View.....	28
Clock Domains.....	29
Master Clocks.....	30
Events View.....	30
Automatic Notification of Device Errors.....	31
IP Address misconfiguration.....	31
Failsafe mode.....	31
Device View.....	31
Device View Menu bar.....	32
File.....	33
Device.....	33
Help.....	33
Device View Toolbar.....	33
Device View Tabs.....	33
Receive Tab.....	34
Available Channels.....	35

Subscribing to Audio Channels in the Device View.....	35
Changing Rx channel labels in the Receive Tab.....	35
Transmit Tab.....	35
Changing Tx channel labels.....	36
Status Tab.....	36
Device Information.....	37
Dante Information.....	37
Clock Synchronization.....	37
Primary Interface.....	38
Secondary Interface.....	39
Device Config Tab.....	39
Configurable Parameters.....	39
Rename Device.....	39
Sample Rate.....	40
Receive Latency.....	40
Reset Device.....	40
Network Config Tab.....	41
Dante Redundancy / Switch Configuration.....	41
Redundant.....	41
Switched.....	41
Switch Configuration.....	42
Addresses.....	42
Baseboard Tab.....	42
Multicast Transmit Flow Configuration.....	43
Presets.....	45
Saving Presets.....	45
Loading Presets.....	45
Troubleshooting.....	47
Messages on Startup.....	47
Computer Configuration Checklist.....	47
Third-party PC or Mac firewall configuration.....	47
Troubleshooting Dante IP Address Configuration.....	48
Correct IP configuration.....	48
Possible IP network configuration mistakes.....	48
PC/Mac IP misconfigurations.....	48
General IP misconfigurations.....	48
Redundant network misconfigurations.....	48
What are the symptoms of using the wrong network interface on my PC or Mac?.....	49
How do I check which network interface my Dante Controller/Dante Virtual Soundcard is using?.....	49
How do I check IP addresses for all devices on my network?.....	49

Troubleshooting Switch Configuration and Cabling.....	50
Symptoms of switch or cabling issues.....	50
Switch and Cabling Checklist.....	50
Index.....	51

Contacts

Audinate Pty Ltd

Level 1, 458 Wattle Street
Ultimo NSW 2007
AUSTRALIA
Tel. +61 2 8090 1000

Postal address

Audinate Pty Ltd
PO Box 855
Broadway NSW 2007
AUSTRALIA

Audinate Inc

1732 NW Quimby Street
Suite 215
Portland, OR 97209
USA
Tel: +1 503 224 2998
info@audinate.com
www.audinate.com

Copyright

© 2012 Audinate Pty Ltd. All Rights Reserved.
Audinate®, the Audinate logo and Dante are trademarks of Audinate Pty Ltd.
All other trademarks are the property of their respective owners.
Audinate products are protected by one or more of US Patents 7747725, 8005939, 7978696, and other patents pending or issued. See www.audinate.com/patents.

Legal Notice and Disclaimer

Audinate retains ownership of all intellectual property in this document.
The information and materials presented in this document are provided as an information source only.
While effort has been made to ensure the accuracy and completeness of the information, no guarantee is given nor responsibility taken by Audinate for errors or omissions in the data.

Audinate is not liable for any loss or damage that may be suffered or incurred in any way as a result of acting on information in this document. The information is provided solely on the basis that readers will be responsible for making their own assessment, and are advised to verify all relevant representation, statements and information with their own professional advisers.

Software Licensing Notice

Audinate distributes products which are covered by Audinate license agreements and third-party license agreements.

For further information and to access copies of each of these licenses, please visit our website:

www.audinate.com/software-licensing-notice

About Audinate

Audinate Pty Ltd is a leading developer of media networking technology whose products and solutions are transforming the way the world interconnects multimedia systems. Audinate's rapidly growing customer base spans the broader international AV industry and includes many key industry brands.

Audinate's hardware and software products and solutions are founded on patented technologies invented by its world-class networking experts. They enable manufacturers and AV system solution providers to produce sophisticated, easy to use, pro-audio quality AV solutions over standard IP networks.

Audinate is based in the United States and in Sydney, Australia.

With Audinate's Dante technology, digital media networking just got easy.

About Dante

Audinate's Dante technology provides high performance digital media networking that meets the quality and performance requirements of professional live sound, AV installations and broadcast and recording systems.

Designed to fully exploit the capabilities of today and tomorrow's networking equipment, Dante provides media transport mechanisms that eliminate many traditional audio network design restrictions. Dante makes it easy to set up robust, flexible digital audio networks with virtually unrestricted performance. A Dante network can be designed with mixed Gigabit and 100Mbps network speeds, simultaneously support audio with different sample rates and bit depths, and even allow the design of network zones with different latencies.

Dante is built on Internet Protocols – not just Ethernet. Because it uses standard IP over Ethernet, Dante is capable of running on inexpensive off-the-shelf computer networking hardware, and with the use of standard QoS can share installed networks with other data and computing traffic.

Dante provides sample-accurate synchronization and can deliver the very low latency required by professional audio. Dante's network-centric, audio-independent approach to synchronization allows perfectly synchronized playout across different audio channels, devices and networks, even over multiple switch hops.

Dante makes networking a true plug-and-play process, allowing automatic device discovery and system configuration. Dante-enabled devices will automatically setup their network configuration and advertise themselves and their channels on the network, reducing complicated, error-prone set-up procedures. Instead of "magic numbers", networked devices and their input and output signals can be named to make sense to the user.

Dante is not restricted to allowing configuration and transmission of audio channels. Dante also provides mechanisms to send or receive control and monitoring information across the Dante IP network, including equipment-specific messages and control specified and developed by a particular manufacturer.

With its strong foundations and links to current and evolving network standards, Dante is able to deliver a level of future proofing otherwise unavailable in other types of digital audio transportation. Dante was designed for Gigabit networks from its inception, and Dante as it exists today already incorporates aspects of the emerging AVB networking standards. Continued evolution of its networking technology is an integral part of the Dante roadmap.

Dante technology is available in ready-to-implement hardware and software products, reference designs and development APIs.

For more information, please visit the Audinate website at www.audinate.com.

Introduction

About Dante Controller

Dante Controller is a software application provided by Audinate which allows users to configure and route audio around Dante networks. It is available for PCs running Windows XP and Windows 7, and Apple Macs running OS X 10.6 and 10.7.

Once you install Dante Controller on your PC or Mac and connect it to a Dante network, you can use Dante Controller to:

- View all Dante-enabled audio devices and their channels on the network
- View Dante-enabled device clock and network settings
- Route audio on these devices, and view the state of existing audio routes
- Change the labels of audio channels from numbers to names that suit you
- Customize the receive latency (latency before play out)
- Save audio routing presets
- Apply previously saved presets
- View and set per device configuration options including:
 - Changing the device name
 - Changing sample rate and clock settings
 - Viewing detailed network information
 - Access the device web page to upgrade firmware and license information (where supported)
 - Identify a device for example by flashing LEDs (where supported)

What's New in version 3.2

This version of Dante Controller includes the following new features:

- [Switch Configuration](#) - supported devices allow specialist switching configurations
- [Device View > Status tab](#) - for supported devices, the 'Device Information' pane in the Device View > Status tab now displays manufacturer, product type and product version information for the device. Dante-specific information for the device (Dante model, Dante software and Dante firmware versions) is now displayed in the 'Dante Information' pane.
- [Device Status View](#) - the 'Type' and 'Version' columns have been renamed as 'Product Type' and 'Product Version'
- Various performance and stability enhancements

Before You Install: Important Notes

Platforms Supported

Dante Controller software is available for Windows XP (32 bit only), Windows 7 (32 and 64 bit), and Mac OS X 10.6 and 10.7 running on Intel architecture.

- A display resolution of at least 1024 x 768 and screen size of at least 19" is recommended for Dante Controller.

Minimum System Requirements

The tables below list the minimum system specifications for your computer to be able to use Dante Controller.

Disclaimer: It is possible that your computer may meet the requirements below, but suffer from some other individual performance limitation related to its particular hardware. Please seek the advice of your computer support administrator.

General

Component	Recommended Minimum Requirement
Processor	1GHz or better
Memory	512Mbyte of RAM
Network	Standard wired Ethernet network interface (100Mbps or Gigabit). Wireless LAN (Wi-Fi) Ethernet interfaces are not supported

Windows

Component	Recommended Minimum Requirement
Operating System	Windows XP SP3 and above (32-bit) Windows 7 (32-bit and 64-bit) NOTE: Both UTF-8 and Unicode are supported EXCEPT for host or device names; the DNS standard does not support Unicode for these

Mac OSX

Component	Recommended Minimum Requirement
Operating System	Mac OS X 10.6 and 10.7 NOTE: Intel architecture only; PPC not supported



Note: If you intend to also install Dante Virtual Soundcard on the same machine as Dante Controller, you will require a machine which meets the minimum system requirements for Dante Virtual Soundcard.

Operating System Updates

Ensure your PC or Mac has the latest Windows or Apple updates installed.

Ensure Bonjour is installed

The Dante Virtual Sound card relies on Bonjour, Apple's Zeroconf implementation.

Bonjour is installed by default on Mac OSX, and no further action should need to be taken.

To download and install the latest version of Bonjour for Windows, visit:

- www.audinate.com/DownloadBonjour

Firewall Configuration

Firewall configuration for Windows Firewall and Mac OSX built-in firewall is automatically handled during installation.

Dante Controller communicates over UDP over the following ports:

- Dante Control and Monitoring: 8700-8704, 8800

If you are using a third-party firewall product, use the port information provided above to configure it accordingly.

Installing Dante Controller

Pre-install Checklist

Have you:

- Read the previous section
- Checked that Bonjour is installed
- Uninstalled all previous versions of Dante Controller, if any
- Checked whether you need to configure your firewall
- Logged in using an account with Administrator privileges
- If you're using Windows, DON'T just Switch User - if you need to change user to become an administrator, log out and log back in as the new user.

Uninstalling Previous Versions

Before installing the new Dante Controller, please uninstall any previous versions you may have.

Windows

To uninstall previous versions of Dante Controller:

- Dante Controller version 2.x must be uninstalled via **Program files > Audinate > Dante Controller > Uninstall**
- Dante Controller version 3.x can be uninstalled via **Program files > Audinate > Dante Controller > Uninstall**, or via **Start > Control Panel > Add or Remove Programs** (called **Programs and Features** in Windows 7)

Mac OSX

To uninstall previous versions of Dante Controller, please use the 'Uninstall' tool available in the new .dmg file. Refer to [Installing Dante Controller on Mac OSX](#) for more detail.

Downloading Dante Controller

Dante Controller is available for download from Audinate's website.

To download a copy of Dante Controller:

1. Go to Audinate's website: www.audinate.com
2. Navigate to **Support > Software Downloads > Dante Controller**
3. If not already logged in, you will be asked to log in or register before continuing
4. Once registered, download the required version of Dante Controller (Mac OSX or Windows XP/Vista)

This will download a self-installing Dante Controller file.

Installing Dante Controller on Windows

Once you have downloaded the self-installing Dante Controller file, navigate to the directory where you have downloaded it (e.g. Desktop).

To install:

1. Double-click on the icon for the self-installing Dante Controller file.
2. A notice may appear, titled **Open File -Security Warning**. This displays the message “The Publisher could not be verified. Are you sure you want to run this software?”
3. Click **Run** to continue.

You should then see the Dante Controller Setup Wizard dialog box.

4. Click **Next** to continue.



Note: If you have already installed Dante Controller, you may be presented with a dialog box directing you to use Add/Remove Programs to uninstall it. The Dante Controller Uninstall program can also be used.

5. Assuming that you do not have an existing copy of Dante Controller installed, you will be presented with the text of the Dante Controller License Agreement. Please read it carefully. You need to check the box to accept the terms in the license agreement, and click **Install**.
6. If you do not accept these terms, click **Disagree** to terminate the installation.

Dante Controller will then be installed. When the installation has completed you will be presented with a dialog box that allows you to select the option of starting Dante Controller immediately on exiting the Wizard.

If you have not installed Bonjour for Windows, the install will show an error message before aborting. Please see the earlier section “Before you install: Important Notes” to locate the Bonjour for Windows installer, and install Bonjour.

Installing Dante Controller on Mac OSX



Note: Previous versions must be uninstalled prior to this installation. Please use the uninstaller provided in the .dmg file if you have a previous version installed.



Note: The Mac OSX Dante uninstaller will uninstall Dante Virtual Soundcard as well as Dante Controller.

To install Dante Controller on Mac OSX:

1. Double-click the Dante Controller .dmg file. A drive icon will appear on your Desktop Finder window. Double click on this to open.
2. Double click the Dante Controller .pkg. This will run the installer.
3. Read the license text, and if you accept the terms of the agreement, click **Agree**.

If you do not accept these terms, click **Disagree** to terminate the installation.



Note: If you have previously installed Dante Controller, uninstall it using the uninstaller provided in the .dmg file before re-installation.

Dante Controller will then be installed.

Dante Basics

Discovery and auto-configuration

When a Dante-enabled device is connected to an IP/Ethernet network, it will automatically:

1. Configure its IP address
2. Advertise itself to allow automatic discovery

Within seconds of a Dante-enabled device connecting to a network, Dante Controller will automatically discover and display the device, allowing you to configure channels and route audio.

Automatic network configuration

A Dante-enabled device connected to a network will automatically setup its own network configuration, including its IP address.

If the network has a DHCP server, which may be the case for installed networks, it will receive its IP configuration using the standard DHCP protocol.

On a network without a DHCP server, which may be the case for temporary or smaller networks, the Dante-enabled device will automatically assign itself an address using link local protocols, in the same way PCs and printers often do.

Automatic discovery

A Dante-enabled device will advertise information about itself to other Dante devices and Dante Controller, including:

- Device name
- Audio channel labels
- Number of audio channels
- Sample rates and bit depths

This information can be seen when viewing a device on Dante Controller, and allows Dante devices to determine compatibility with other devices, such as compatible sample rates to allow audio to be routed.

Differentiating between input and output channels

Channels are classified according to whether they put audio data onto or take audio data off the network:

- A channel that puts audio data onto the network is known as a transmitting, Tx or output channel.
- A channel that takes data off the network is known as a receiving, Rx or input channel.

Device and Channel Labeling

In Dante, devices and audio channels are identified by labels, not “magic numbers”. Labels can be customized.

- Dante routing is performed using the device and channel labels. A receive channel can be subscribed to the name of a transmit channel at a device.

Example: “Analog L@my-transmitter” describes a channel named “Analog L” on a device named “my-transmitter”. Device labels must be unique on a Dante network. Channel labels must be unique on the device.

- If a device or channel is relabeled, Dante routing considers it to be a different device or channel. If another, new device or channel is then given the old label, Dante routing will route from the new device in place of the previous device.

Example: The power supply on “stage-box” fails and “stage-box” needs to be replaced. The old “stage-box” is removed, and a new box is plugged in and labeled “stage-box”. Dante receivers previously subscribed to the old “stage-box” will now automatically restore their subscriptions to the new “stage-box”.

- Device labels must be unique on the network. If you attempt to rename a device using Dante Controller to a name already in use on the network, Dante Controller will notify you and refuse to change the name.

Example: There is an existing device on the network called “MY16-slot1”. If user attempts to rename another device to “MY16-slot1” Dante Controller will notify the user that the name is already in use. The device will not be renamed.

- If a new device is added to the network with a name that already exists, a name conflict is detected, and one of the devices will rename itself by appending (2) to its name. This device will not be able to transmit audio until it is renamed.



Note: A device that has been renamed with (2) appended (e.g. “MY16-slot1 (2)”) WILL NOT BE ABLE TO TRANSMIT AUDIO until it is renamed. The device label must be changed by the user to be a valid non-conflicting name before the device can become fully functional.

Rules for Labels

- All Dante labels are up to 30 characters in length. Label comparisons are case-insensitive; “Guitar” and “guitar” are treated as the same label. Unicode and non-roman characters are not supported.
- Device labels should follow Domain Name System (DNS) hostname rules. Legal characters are A-Z, a-z, 0-9, and '-' (dash or hyphen). Device labels must begin with A-Z (or a-z).
- Tx channel labels may use any character except '=' (equals), '.' (full stop or period), or '@' (at). Tx channel labels must be unique on a device. Tx channel labels do not need to be unique on the network as they are always qualified by device (channel@device).
- Rx channel labels follow the same rules as Tx channel labels.

Routing Audio

Routing Terminology

- **Device:** A device means a Dante-enabled device, and more specifically that component of the audio equipment that implements the Dante interface. A Dante device typically has Tx and Rx channels and other routing-related properties.

- **Transmit (Tx) channel:** A transmit channel transmits audio from the audio hardware onto the network.
- **Receive (Rx) channel:** A receive channel receives audio from the network and sends it to the audio hardware.
- **Flow:** Dante audio routing creates flows. Each flow carries several channels of audio from a transmitter to one or more receivers. Unicast routing creates flows to single receivers. Multicast routing creates flows that can be received by multiple receivers. Multicast flows are assigned IDs enabling them to be identified in Dante Controller.
- **Unicast routing:** Unicast flows are point-to-point from a single transmitter to a single receiver. Unicast flows typically have room for 4 channels of audio.
- **Multicast routing:** Multicast flows are one-to-many from a single transmitter to any number of receivers. Use Dante Controller to choose what channels are to be multicast. Unlike unicast routing, multicast flows consume network bandwidth even if there are no receivers, but do not require additional bandwidth to add more receivers.
- **Subscription:** A subscription configures a receive channel to receive audio from a transmit channel on another Dante device.
- **Subscription status:** For a receive channel, subscription status indicates whether it is subscribed, whether it is receiving unicast or multicast audio, whether the subscription is OK, or whether an error has occurred.

Subscription

Dante routing is performed by associating a receiving (Rx) channel with a transmitting (Tx) channel. This is called subscription.

Example: Route Tx channels 1 and 2 (labeled “Audio L” and “Audio R”) on the device labeled “Source” to Rx channels 3 and 4 on the device labeled “Dest”.




Rx channels 3 and 4 on “Dest” are subscribed as follows:

- 3. Audio L@Source
- 4. Audio R@Source

Dante will perform the necessary audio routing to deliver the audio from the Tx channels to the Rx channels.

Redundancy

Many Dante devices support redundant audio routing. These devices have two network interfaces, labeled primary and secondary. Primary interfaces should be connected to one physical network. If redundancy is being used, secondary interfaces should be connected to a second separate network. Secondary interfaces cannot communicate with primary interfaces.



If the secondary network is connected to a device that supports redundancy, it is enabled automatically. Audio data is transmitted on both the primary and secondary networks simultaneously. In the event of a failure on one network, audio will still continue to be received via the other network.

 **Note:** Dante redundancy requires that both the primary and secondary interfaces on any redundant device are connected using the same link speed. For example, if the primary interface is connected to a 1 Gbps switch port, the secondary interface must also be connected to a 1 Gbps switch port. Similarly, if the primary interface is connected to a 100 Mbps switch port, the secondary interface must also be connected to a 100 Mbps switch port.

 **Note:** Dante devices that do not support redundancy must be connected to the primary network only. Dante Controller must be connected to the primary network.

Audio Formats

Different Dante devices may support different audio formats. Most Dante devices support either 48 kHz 24-bit PCM or 96 kHz 24-bit PCM. Some devices can be switched between 48 kHz and 96 kHz, but will not support both at once.

It is only possible to set up a route between channels which have a common audio format. Channels having incompatible formats will be shown in grey and will not be routable.

Flows

Dante audio routing creates 'flows'. Each flow carries one or more channels of audio from a transmitting device to one or more receiving devices. There are two types of flow, unicast and multicast.

Unicast routing creates flows to a single receiving device; a unicast flow typically assigns space for 4 channels of audio. Unicast flows are setup when a receiver subscribes to an available audio channel, and are automatically removed when the receiver unsubscribes from all channels in that flow.

Multicast routing creates flows that can be received by multiple receivers. Multicast flows are assigned IDs enabling them to be identified in Dante Controller and to facilitate their removal. In contrast to unicast

flows, multicast flows must be set up on the transmitting Dante device before receivers can subscribe to these flows.

Advanced Routing: Using Multicast

Dante routing is unicast by default. This means that a separate flow is set up between each transmitter and receiver. If several receivers are all subscribed to the same channels of a transmitter, it may sometimes be more efficient to use *multicast*.

Multicast sends the same set of channels to multiple receivers. In practice, this usually means that the audio flow is flooded throughout the network. If many receivers want the same channels, using multicast can reduce overall network use, especially on the transmitter, because only one copy of each audio channel needs to be sent, rather than many.

Dante receivers will automatically prefer multicast to unicast if it is available. This means that if a new multicast flow is created containing the channels that a receiver is currently receiving as unicast, the receiver will switch over to receiving audio from the multicast flow and the unicast flow will be removed.

Clock Synchronization

All Dante-enabled devices use the IEEE 1588 Precision Time Protocol (PTP) across the network to synchronize their local clocks to a master clock, providing sample-accurate time alignment throughout the network.

One Dante device will be elected as the PTP Master Clock for the network; all other Dante devices act as a PTP Slave Clocks to the elected master clock. Although many Dante devices may be capable of becoming PTP Master Clock, only one device will win the election. Devices with clock inputs (e.g. word clock or AES3) will be preferred in the election process. A gigabit connected device is preferred over a device connected via 100Mbps. A tie-breaker rule of the lowest MAC address is used if several equivalent candidate master clocks are available. The election process may be overridden by manually setting "PTP Preferred" master on a device.

Dante Clock Types

Each Dante hardware device can derive its clock from either its high-quality onboard clock circuit, or an externally connected word clock. In the case of Dante Virtual Soundcard, the computer's clock will be used.

Clock Settings

Slave to External Word Clock

A Dante device with "Slave to External Word Clock" set will use the external word clock from its host equipment to tune its onboard VCXO. A Dante device with this attribute set will become the PTP Master Clock, unless there is another Dante device present with "Preferred Master" set.

Preferred Master

Sometimes it may be necessary to force a particular device to provide the PTP Master Clock. A Dante device with "Preferred Master" set will always be chosen as the PTP Master Clock. If more than one device has "Preferred Master" set, the device with the lowest MAC address will be chosen.

Clocking and Synchronization in Redundant Networks

In a redundant network, the clock synchronization protocol operates over both primary and secondary networks. Each network will have a designated PTP master clock; usually this will be the same device on both networks. If this is not the case (e.g. if a non-redundant device is designated Preferred Master) then one device will bridge the clock synchronization information from the primary to the secondary network, ensuring that all devices derive their clock from the same source. Redundant PTP Slave clocks will synchronize their local clocks based on information from one of the networks they are connected to. In event of a failure on one network a redundant device will continue to receive clock synchronization information over the other network.

Latency

In Dante, variation in latency in the network is compensated for at the receiver. Each receiver has an Rx latency setting. This setting defines the latency between the timestamps on the incoming audio samples and when those samples are played out.

The typical default latency for a Dante device is 1 msec. This is sufficient for a very large network, consisting of a Gigabit network core (with up to 10 hops between edge switches) and 100 megabit links to Dante devices. Smaller, Gigabit-only networks can use lower values of latency (down to below 200 μ sec). Recommended latency settings are displayed in Dante Controller and may also be found in the documentation accompanying the product.

Latency and the Dante Virtual Soundcard

The Dante Virtual Soundcard allows a standard Apple Mac or Windows PC to function as a Dante device. Because the Dante Virtual Soundcard runs on a general purpose computer without special hardware to support Dante timing requirements, additional latency needs to be added to connections received from a Dante Virtual Soundcard transmitter.

The Dante Virtual Soundcard is configured with custom latency values for reliable operation. Dante devices with Rx channels that are subscribed to Tx channels from a Dante Virtual Soundcard transmitter will automatically configure themselves to use these higher latency values for those channels only. The latency on all other subscriptions on the receiver is unaffected.

Dante Control and Monitoring

In addition to automatic configuration and discovery, audio transport and routing, Dante-enabled devices can also be controlled and monitored in various ways. This includes being able to view and change specific parameters, such as clock configuration settings. Dante devices are also capable of sending status events that can be viewed using Dante Controller. Status events include changes in clock status, or network interface changes.

Starting Dante Controller

Where to find the Dante Controller application

Windows

By default Dante Controller will be installed in

C:\Program Files\Audinate\Dante Controller\

It can be started in several ways:

- Using the Start menu: **Start > Programs > Audinate > Dante Controller > Dante Controller**
- Run by going to **Start > Run** and entering
C:\Program Files\Audinate\Dante Controller\DanteController.exe
in the dialog box
- Navigate to the directory where it is installed, and double-click the Dante Controller icon: 

Mac OSX

The Dante Controller application will be installed in the Applications folder.

To start:

- Navigate to **Applications** folder, and double-click the Dante Controller icon: 

Or:


- Drag the icon to the Dock and click on it

Configuring Dante Controller

Network Interface Selection

Dante Controller communicates with other Dante devices on their primary network. Dante Controller needs to know which of the network interfaces of the host computer is connected to the primary Dante network.

The first time Dante Controller is run, the user may be presented with the **Configure Dante Interfaces** dialog box providing a list of interfaces from which to select the primary Dante interface. Once an interface has been selected it is remembered for future use and this dialog box will not be shown when Dante Controller is run subsequently.



The selected network interface can be changed via the 'interface selection' button  in the **Network View** toolbar of Dante Controller, which also brings up this **Configure Dante Interfaces** dialog box.

 **Note:** You MUST have a standard wired Ethernet network available and connected to use Dante Controller. Wireless and other non standard wired Ethernet interfaces are NOT shown in this dialog box, and cannot be selected.

 **Note:** All Dante applications on the same PC or Mac have a shared understanding of which interface is the primary Dante interface. For example, if you have installed Dante Virtual Soundcard on the same PC as Dante Controller and a new primary interface is selected from within Dante Virtual Soundcard, Dante Controller will automatically switch to the newly selected interface and begin operating on that interface.

Using Dante Controller


Dante Controller presents the user with two types of window or view: **Network View** and **Device View**.

 **Important:** After making changes to Dante network routing (e.g. subscriptions, device names, channel labels etc.) please wait at least 5 seconds before disconnecting or powering down any affected devices. This ensures that the new information has been properly saved to the devices. Device configuration (e.g. sample rates, latency, clock settings) are saved instantly.

 **Note:** Mac OSX users: Please note that the key combinations shown below are for Windows users. When using Dante Controller on a Mac, please use the “Command (CMD)” or “Apple” key instead of the “Control” key when following the instructions below, and substitute standard Mac key combinations where applicable - see the Dante Controller menu for details.

Network View

When Dante Controller is started it always begins by presenting the Network View:



Network View Menu bar

The menu bar in the Network View contains three menus: **File**, **Device** and **Help**.

File

- Load Preset (Ctrl+L): loads a configuration from a file
- Save Preset (Ctrl+S): saves configuration for currently displayed devices to a file
- Exit (Alt+F4): Exits Dante Controller

The use of Presets is described in detail later in this guide.

Device

- Refresh (F5): Refreshes the displayed network / device data
- Device View (Ctrl+D): Opens a new Device View window

Help


- About: Shows Dante Controller version and current log file
- License: Displays the license text
- Contents (Shift+F1): Opens a help window and displays help contents

Network View Toolbar

Below the menu bar there is a toolbar with a series of icons:



The first three of these are shortcuts to Refresh , Load Presets and Save Presets functions. The fourth icon provides a way of examining and changing the Dante network interface setting, and brings up the following dialog box (see [Configuring Dante Controller](#)):



Network View Tabs

There are four sub-views within the Network View that can be selected by clicking on the tabs below the menu bar and toolbar. These are as follows:

- Routing
- Device status

- Clock Status
- Events

The use of each of these tabs is described in the next section.

Sub-views within the Network View


Routing View

When Dante Controller is started, it always displays the Routing Tab within the Network View. In this view the network is shown in the form of a grid. Devices with Tx channels are displayed along the top row of the grid, and those with Rx channels are displayed along the left-hand column of the grid. Initially a collapsed view is presented; individual channels cannot be seen.

Note: If a device name is shown in red, it means Dante Controller has automatically detected an error condition. Double-click the device name to see more information. Refer to [Automatic Notification of Device Errors](#) for further explanation.

Note: If a device has Tx and Rx channels, it is shown both along the top row of the grid and also along the left-hand edge.

Expanding the Routing View



The Rx channels associated with any device can be displayed by clicking on the [+] to the left of the device name in the left-hand column of the grid. The Tx channels associated with any device can be displayed by clicking on the [+] above the device name on the top row of the grid. When this action is performed the grid view expands to show each channel of the device, and the [+] becomes a [-]. Clicking on [-] collapses the view.

The Rx channels associated with all devices can be simultaneously expanded by clicking on the [+] of “[+] [-] Dante Receivers” at the top of the left-hand column. Similarly, the Tx channels associated with all devices can be simultaneously expanded by clicking on the [+] of “[+] [-] Dante Transmitters” at the left of the top row. Clicking on [-] will collapse the view.

Customizing the Network View

The Network view can be customized using the “Filter Transmitters” and “Filter Receivers” boxes below the Audinate logo in the top left-hand corner. Any text string typed into the box will filter out and only display devices that contain that text string in either a device or channel name. The filtering is case-insensitive. For example, in the Dante Controller Network view above, entering the string “dme” in either of the Filter fields would display only the MY16-DME-Slot devices and their channels.

Device Channels


A Dante device has a number of channels associated with it. These are either transmit (Tx) or receive (Rx) channels. Receive channels and devices are listed down the left side of the grid. Transmit channels and devices are listed along the top of the grid.

Transmit channels are advertised on the network. A receiver uses this advertisement to establish a subscription to the channel. A transmit channel can be sent to multiple receivers using unicast or multicast.

Receive channels are connected to transmit channels via a subscription. Each receive channel will receive audio over the network from at most one transmit channel.

Device Status View

The Device Status view can be displayed by clicking on the Device Status tab within the Network View window.



The Device Status view presents a network wide overview of device configuration and operating information. The tabular view presents the following information, in columns from the left, as follows:

- **Device Name:** The label currently associated with the device
- **Product Type:** The product type
- **Product Version:** The product version
- **Primary Address:** The IP address assigned to the primary interface. IP addresses are currently assigned via DHCP or automatically self-assigned. Self assigned addresses on the primary interface will be in the 169.254.X.Y range.
- **Primary Link Speed:** The Ethernet link speed that the primary interface is currently operating over (i.e. 1Gbps or 100Mbps).
- **Secondary Address:** The IP address assigned to the secondary interface. IP addresses are currently assigned via DHCP or automatically self-assigned. Self assigned addresses on the secondary interface will be in the 172.31.X.Y range.

IP Address	Assigned P address
Link Down	Secondary Dante interface supported but not connected
Not supported	Secondary Dante interface not supported

- **Secondary Link Speed:** Indicates the Ethernet link speed that the secondary interface is currently operating over (i.e. 1Gbps or 100Mbps). Other values as described above for Secondary Address.




Note: A Dante interface may have a preferred link speed. Where it does and the primary and/or secondary interface is not operating at that preferred link speed, the values in the Primary Link Speed and/or Secondary Link Speed columns will be presented in red.



Note: Older Dante devices may not support querying of some of this information. In this case the relevant column will display “Not Supported”.

Clock Status View

The Clock Status tab within the Network View provides a network wide overview of the clocking state within the network.



This view provides a convenient way of quickly scanning the network for clock information. The view is in table format, with the following fields for each device, in columns from the left, as follows:

- **Device Name:** the label currently associated with the device.
- **Primary Interface Clock Status:** indicates the state of the PTP clock for the primary network interface. Clock Status values and their meanings are as follows:

Master	Device is the current PTP Master Clock on the primary Dante network
Slave	Device is a PTP Slave on the primary Dante network
Passive	Device is not using clock synchronization information from this interface
Link Down	The interface is not connected to the network
Not Supported	Where the device is non redundant the second interface is <i>Not Supported</i>
Not Available	The device does not support clock status reporting

Devices that are configured with sample rate pull-up/down are shown with the relevant pull-up/down value against their Clock Status. For example, a device acting as master clock with +4.1667% pull-up will be shown as **Master +4.1667%**. See [Clock Domains](#) for more information.



Note: Other transient clock states exist, which are not listed above.

- **Secondary Interface Clock Status:** indicates the state of the PTP clock for the secondary network interface of a redundant device. The pull-up/down setting for the device is also shown.
- **Clock Role:** shows the capabilities of the device, and allows the user to select 'Preferred Master' status for a device. The possible values are:

Preferred Master (checked or unchecked)	Device may act as master clock
Slave only	Device is not capable of becoming a PTP master
Not Supported	Setting of clock role is not supported by this device
Not Available	Clock Role information is not available for this device

Checking 'Preferred Master' raises the priority of the device in the master clock election. If only one device on a particular clock domain has this box ticked, it ensures that the selected device becomes master clock (for the relevant clock domain). When multiple devices have their Preferred Master box ticked, the master will be elected from within that group. This is a convenient method of controlling the group of devices from which the master can be selected.

- **Slave To External Word Clock:** where a device can be slaved to an external Word Clock the value 'Yes' (and a check box) will appear in this column. When checked, this will force the device to derive its local clock from the external word clock source. This will also ensure that this Dante device becomes master clock for the relevant clock domain (unless another device has 'Preferred Master' selected). It is not normal practice to configure more than one device per clock domain with an external clock source. In this case, the user is assumed to have synchronized external word clock sources (e.g. house clock). Where a device does not support slaving to an external Word Clock the value in this column will be 'Not Supported'.



Note: Older Dante devices may not have the ability to report their clock status. In such cases, regardless of whether they are master or slave or have some other status, their status will be shown as "Not Available".

Clock Domains

Dante Devices that are *not* configured with sample rate pull-up/down operate on the default clock domain, using the default clock. Devices that *are* configured with sample rate pull-up/down operate on separate 'clock domains', which have their own dedicated PTP clocks, adjusted to account for the pulled up/down sample rates.

Clock domains are not physically separated, they all exist on the network simultaneously. Devices with pull-up/down synchronise to the appropriate clock for their pull-up/down setting, and ignore other clocks. Those devices are shown with the relevant pull-up/down value against their Clock Status in the Clock Status tab.

Dante devices can only transmit audio to, and receive audio from other devices on the same clock domain. For example, a device with zero sample rate pull-up/down operates on the default clock domain, and cannot transmit audio to, or receive audio from any devices on the +4.1667% clock domain, or the -1% clock domain, etc.

Up to 5 separate clock domains can be supported at any one time. All clock domains have their own master clock.

Master Clocks

The Dante network master clock, called the 'Grand Master', is displayed at all times in the center of the toolbar of the Network View. This is the device that is providing the time sync source for all devices on the network.


If multiple clock domains are in use, the Grand Master for each domain is shown, in a comma-separated list.

The master clock is chosen automatically through an election process, though there are user configurable parameters that allow prioritization of some devices in the master clock election. Configuring a device to have an external word clock source will force that device to become master clock, unless another device has 'Preferred Master' set.

Checking the 'Preferred Master' flag will always result in that device (or the device with the lowest MAC address, if more than one device has been checked) becoming master clock for that domain.

Events View

The Events tab within the Network View provides information on significant changes and failures in the network.



Dante Controller continually monitors Dante devices and the network as a whole. It is able to watch for problematic configurations, unexpected problems and communication failures between itself and Dante

network devices. Events are displayed are stored in an event log. Each incident is given a severity grading, as follows:



Information



Warning



Error

Events are also written to a log file. Each time the controller starts it creates a new log file with a time-stamped filename, to avoid overwriting previous logs. The events pane provides a button enabling deletion of log files more than seven days old.

You can find the path to these log files under **Help > About**.

Automatic Notification of Device Errors

Dante Controller is able to identify several types of problems that a Dante device may experience. A device that is found to have problems will have its device name displayed in red. Additional information about the problem can be found by double-clicking on the device.

A device displayed in red will either have entered **failsafe mode** or have an identified issue with its IP configuration. These states are described in more detail below.

IP Address misconfiguration

Dante networks use IP Addressing to communicate. Incorrect address configuration can make it hard or impossible for a Dante device to communicate. Dante Controller attempts to identify and report several types of address misconfiguration, including:

- Having multiple DHCP servers on the same network
- Incorrectly configured static IP addresses
- Connecting the secondary interface of a Dante device to the primary network
- Different interfaces on the same device using the same IP address subnet

If you need further information, please refer to the [Troubleshooting](#) section.

Failsafe mode

A device will enter failsafe mode when the firmware image stored on the board has become corrupted. Although rare, this can occur when:

- The firmware update process is interrupted by power loss or network failure
- The firmware image itself that was used in an upgrade is corrupt


If your device enters failsafe mode, please use the Failsafe Recovery function in the Firmware Update Manager application (if available) or contact your device manufacturer.

Device View

The Device View is used to view and modify detailed information and settings for a specific device. Device view can be activated by double-clicking on a device name in the Routing View within the Network View

window, or by selecting **Device View** from the **Device** menu (CTRL-D or CMD-D) in the Network View window. The Device View opens in a new window.

Note: Mac OSX users: Please note that the key combinations shown below are for Windows users. When using Dante Controller on a Mac, please use the “Command (CMD)” or “Apple” key instead of the “Control” key when following the instructions below, and substitute standard Mac key combinations where applicable - see the Dante Controller menu for details.



The label of the device being viewed is displayed in the middle of the toolbar. In the screenshot above MY16-Slot2 is the device being displayed in the drop-down list box.

The device viewed can be changed by selecting another device from the drop-down list.

Multiple Device View windows may be opened from the Network View, so that several devices can be examined simultaneously.

The Device View has up to five sub-views allowing the user to see different information relating to a specific Dante device:

- Receive: display and configure device's receive (Rx) channels
- Transmit: display and configure device's transmit (Tx) channels including multicast
- Status: device software, clock and network status information
- Config: rename device and set other attributes as relevant to device type
- Baseboard: only available when the Dante device is mounted on a Dante PDK audio baseboard (NOTE: the device must be in SPI Master mode)

Device View Menu bar

The menu bar in the Device View contains three menus: File, Device and Help.

File

- Load Preset: loads a configuration from a file
- Save Preset: saves configuration for currently displayed devices to a file
- Exit: Exits Dante Controller

The use of Presets is described in detail later in this guide.

Device

- Refresh: Refreshes the displayed network / device data
- Device View: Opens a new Device View window

Help

- About: Shows Dante Controller version and current log file
- License: Displays the license text
- Contents: Opens a help window and displays help contents

Device View Toolbar

The Device View toolbar contains 4 buttons: Refresh, Web Configure, Identify, and Multicast Configuration. These provide the following functionality:

 Refresh	Re-load routing and configuration information for the current device
 Web Config	Some Dante devices can be configured via a web interface. This button opens a web browser window which can be used to perform functions such as firmware upgrades. This feature is not supported on all Dante devices.
 Identify	Identify the current device by, for example, causing its LEDs to flash. Note that this feature is not supported on all Dante devices.
 Multicast	Configure multicast transmit flows on the current device.

The toolbar also provides a drop down list of all available devices on the network which allows the user to switch to a different device.

Device View Tabs


Below the toolbar, the Device View window has five tabs: Receive, Transmit, Status, Device Config and Network Config, which are described in detail below.

An additional tab, Baseboard, is only available when the Dante device is a module mounted on a Dante PDK baseboard (and is in SPI Master mode).

Receive Tab

The Receive tab presents information about all channels being received, and able to be received by the current device. The tab is arranged into two areas

- **Receive Channels:** Lists the Rx channels in the left pane of the window. It shows whether or not they are connected and, if connected, the channel they are connected to and the status of that connection.
- **Available Channels:** On the right pane of the window, lists the Tx channels from other devices that are available for subscription by the current device.



The Receive Channels view on the left side of the tab contains three fields:

- **Channel:** An editable field that lists the receive channel labels for the current device. These can be edited to change the current label of a receive channel.
- **Connected To:** Lists the Tx channel that the receive channel is currently subscribed to.
- **Status:** Lists the status of both primary and secondary subscriptions using the following icons:

	Subscription is OK and audio should be flowing
	No subscription, or a subscription error
	Subscription is via unicast connection
	Subscription is via multicast connection

A particular subscription may have several symbols in its Status column. Common status icon combinations and their meanings are as follows:

 	A Unicast device successfully subscribed to a transmitter
  	Redundant device successfully subscribed on both primary and secondary to the transmitter via unicast
  	Redundant device successfully subscribed on both primary and secondary to the transmitter via multicast
  	Redundant device successfully subscribed on primary only to the transmitter via unicast. This is typical when the secondary interface is not connected

Available Channels

The Available Channels view on the right side of the tab lists the devices and advertised channels available on the network. Devices that are grayed out indicate that this receiver cannot subscribe to those channels or devices. This is typically because of a mismatch in parameters (e.g. sample rate incompatibility etc.), or because a device cannot route audio to itself.

Subscribing to Audio Channels in the Device View

Subscriptions are created by selecting a channel from the Available Channels list in the right-hand pane of the Receive Tab, then dragging and dropping it onto the appropriate receive channel in the left-hand pane of the Receive Tab.


Multiple channels can be selected and then dragged and dropped onto the Receive Channels Tab to make several subscriptions simultaneously.

Changing Rx channel labels in the Receive Tab

Rx channel labels can be changed by double clicking on the channel label and typing in a new value.

Transmit Tab

The Transmit tab is used to inspect and modify the transmit configuration of a device.



The Transmit Tab is arranged in two areas:

- **Transmit Channels:** The area on the left pane of the tab shows the Tx channels for the device, and any user-defined channel label. It allows the user to create labels for transmit channels. Input to the table is filtered to prevent illegal characters from being used in channel labels.
- **Transmit Flows:** The area on the right pane of the tab indicates how many unicast flows are currently in use, as well as the multicast transmit flows that have been configured on the device. Multicast flows are listed in ID order, including the channels contained within the flow.




Note: Unicast flow details are not displayed in the transmit flow window. The total number of transmit flows currently in use is shown at the top of the pane. The total number of flows is the sum of the unicast and multicast flows in use. The maximum number of flows that the device supports is also shown (16 in the screenshot above).

Changing Tx channel labels

To change a Tx channel label double click on the label and type in a new one. Tx channel labels must be unique on a single device.

Status Tab

The Status tab is used to obtain current information about a Dante device.



The tab is divided into sections. The information presented on this tab can be very useful when investigating networking or clocking issues in the system. The Refresh button  can be used to update this information if required.



Note: Not all Dante devices support the display of all of this information.

Device Information

This provides the following general information about the device:

- **Manufacturer:** The name of the device manufacturer.
- **Product Type:** The type of device.
- **Product Version:** The product version.

Dante Information

This provides Dante-specific information about the device:

- **Model:** The Dante device type.
- **Software Version:** The version of the Dante software running on the device.
- **Firmware Version:** The version of the Dante firmware running on the device.

Clock Synchronization

This provides the following information about device clocking:

- **Status:** Locked indicates that the device is locked to the network PTP clock. Not Locked indicates that the interface has not achieved lock with the network PTP clock.
- **External Word Clock:** No indicates that the device has been configured to use the internal clock source. Yes indicates that the device has been configured to accept an external word clock source. NOTE: If the device is configured to accept an external word clock source then it is important to make sure that the host equipment has been set-up to provide a word clock to the Dante device. Check your product manual for more information.
- **Preferred:** No indicates that the card has not been set to preferred master mode. Yes indicates that the card is set to preferred master mode.
- **Frequency Offset:** Indicates the offset from the network clock master measured in parts-per-billion.

Primary Interface

Provides the following information about the primary network interface:

- **IP address:** The IP address currently assigned to the interface
- **MAC address:** The Media Access Control address of the interface, associated with the Ethernet layer
- **Tx Utilization:** Shows the current total transmit bandwidth in use
- **Errors:** (on the same line as Tx utilization) shows the number of transmit Cyclic Redundancy Check (CRC) or packet errors detected since the device was last started
- **Rx Utilization:** Shows the current total receive bandwidth in use
- **Errors:** (on the same line as Rx utilization) shows the number of receive Cyclic Redundancy Check (CRC) or packet errors detected since the device was last started



Note: The Rx Utilization includes not only network traffic destined for the Dante device, but any other multicast or broadcast traffic received at this network interface



Note: As a rule of thumb neither the Rx nor the Tx utilization should exceed about 85% of the link speed in order to guarantee good clock synchronization performance (links are full duplex).

The graphic also indicates the speed and connected state of the interface as follows:



Indicates that the interface is running at 1Gbps.



Indicates that the link is operating at 100Mbps



Indicates that the link is not connected or that there is an error. The IP address will read N/A, and Tx and Rx utilization will be 0 kbps.

Secondary Interface

This provides the same information for the secondary interface that is provided for the primary interface, as described above.




Note: The secondary network interface will only be displayed if the device supports redundancy.

Device Config Tab

This tab on the device view window allows the user to configure device specific parameters. The specific options available will depend on the capabilities of the device. In the case where a device does not support configuration via Dante Controller, the tab will be disabled.



Note: Dante Virtual Soundcard does not have a Config Tab available on Dante Controller. The Dante Virtual Soundcard User Interface on the PC or Mac must be used to configure these devices.



Configurable Parameters

Rename Device

Allows the user to enter a new Dante 'friendly name' for the device. The text field will contain the current name. Legal characters for a Dante device name are "a-Z", "0-9" and "-". The name cannot start with a number and cannot include a space or any other character that is illegal within the Domain Name System (DNS) that is used to specify web and email addresses on the Internet. Input is filtered to prevent renaming using illegal characters. If the name entered is already in use by another device on the network, Dante Controller will notify the user and refuse to rename the device.

Example: there is an existing device on the network called “MY16-slot1”. If user attempts to rename another device to “MY16-slot1” Dante Controller will notify the user that the name is already in use. The device will not be renamed.

If a new device is added to the network with a name that already exists, a name conflict is detected, and one of the devices will rename itself by appending (2) to its name. This device will not be able to transmit audio until it is renamed.



Note: A device that has been renamed with (2) appended (e.g. “MY16-slot1(2)”) WILL NOT BE ABLE TO TRANSMIT AUDIO until it is renamed. The device label must be changed by the user to be a valid non-conflicting name before the device can become fully functional.

Sample Rate

- Shows the current sample rate of the device, and allows the user to change the operating sample rate of the Dante device. This may require the device to be rebooted to take effect. All sample rates that the device supports are shown in the drop down box.
- Shows the current pull-up/down setting for the device, and allows the user to change the pull-up/down setting. The pull-up/down setting can be used to adjust the sample rate of the device to synchronise audio with video that has undergone frame rate conversion. For example, to synchronise Dante audio with video that has been converted from 24 fps to 25 fps, set the sample rate pull-up/down for any relevant Dante audio devices to +4.1667%.



Note: Changing the sample rate pull-up/down for a device places that device in a dedicated clock domain. Dante devices can only transmit audio to, or receive audio from other devices on the same clock domain. See [Clock Status View](#) for more information.

Receive Latency

Shows the current receive latency setting and allows the user to change the operating receive latency for the selected device. Selecting one of the values and clicking OK will apply the latency to all flows that the device is receiving. Some older Dante devices may show Current latency: dynamic, which is a legacy mode of operation that negotiates a minimum latency based on device specific defaults. Selecting a specific latency value (e.g. 1msec) will override the dynamic latency mode.



Note: The 0.15 msec setting is unavailable for devices that include an internal switch.



Warning: changing the latency value will cause disruption in the audio while the flows are re-established at the new latency setting.

Reset Device

Allows you to remotely reboot the Dante interface, and also to reapply factory settings. Rebooting the Dante device may also require the audio equipment that contains the device to be reset.


Factory Reset wipes the following device configuration settings:

- User-defined device name
- User-defined channel labels
- Clock configuration (clock master / external clock master setting)
- Static IP addresses

- Redundancy configuration
- Sample rate setting (including pull-up/down)
- Latency setting
- Any existing audio routes

Network Config Tab

Use the Network Config Tab to toggle supported devices between Redundant and Switched modes, and to specify static IP addresses for a device's Ethernet ports.



Dante Redundancy / Switch Configuration

Depending on the manufacturer's configuration of a device, it may be possible to toggle the device between Redundant and Switched modes, or to select a Switch Configuration.

Redundant

When a device is set to Redundant, the device will duplicate Dante audio traffic to both Ethernet ports, allowing the implementation of a redundant network via the secondary port. Not all devices support redundancy.

Switched

When a device is set to Switched, the secondary Ethernet port will behave as a standard switch port, allowing daisy-chaining through the device.

Switch Configuration

Certain devices support specialist switching and/or redundancy configurations for the Ethernet ports. For these devices, the top pane of the Network Config tab will be titled 'Switch Configuration'. Please refer to the manufacturer's technical documentation for information on the supported switching configurations for the device.

Addresses

Dante devices obtain IP addresses automatically by default, and in the vast majority of circumstances there is no need to change the Addresses settings. However, static IP addresses can be assigned if necessary.

To assign a static IP address:

1. Select 'manually configure an IP Address' for the appropriate Ethernet port.
2. Enter the IP Address and Netmask.
3. Click **Apply**.

The DNS Server and Gateway settings are optional - the device will use network defaults if they are not specified.

Click **Revert** to revert back to the previous settings.



Note: Assigning static IP addresses requires a device reboot.

Baseboard Tab


This tab on the device view window will almost always be visible but grayed out and unable to be selected. It is only available if a newer model Audinate Dante module is being used with an Audinate development board.



Note: This section is only relevant if you are using an Audinate Dante PDK (Product Development Kit) with an Audinate Dante module running 3.3.x software. Older Dante modules have these settings available through their web interface.




Note: Please refer to your Dante PDK documentation for information about these settings and how to use them.



Multicast Transmit Flow Configuration

Clicking on the Multicast Configuration button in the Device View (regardless of which tab view is currently displayed) will open a Create Multicast Flow dialog box that allows the user to select individual channels to add to a new multicast flow.



The window shows a list of the Tx channels for the device and allows the user to add them to the new multicast flow that is being created, by checking the tick box next to each channel name. Once the user has selected all the channels required, the multicast flow can be created by clicking on the Create button at the bottom of the dialog box. To abandon creating a new multicast flow, click on the Cancel button.

A single multicast flow can contain up to the maximum supported channels per flow for this device. This is displayed at the top of this window and is 8 channels for this device. If the user selects more than the

maximum allowed channels per flow, multiple flows will be created. Once a flow has been created, it will appear in the list of flows in the transmit pane, along with the channels contained within that flow. Channels cannot be added to or removed from existing flows. Each time the dialog is used to select additional channels, a new multicast flow will be created.

By default, Dante devices "prefer" multicast over unicast. When a user clicks on a transmit channel to make a subscription, the receiver will automatically connect to the channel via a multicast flow if one exists. Likewise, when a channel that did not form part of an existing multicast flow is added to a new multicast flow then any existing unicast subscription to that channel will automatically switch over to use the new multicast flow.

Care should be taken when deleting a multicast flow, as the existing subscriptions will convert back to unicast. This has the potential to result in exceeding the link capacity or maximum number of flows at the transmit device as multiple unicast flows will be established between the transmitter and its receivers. It may be advisable to remove some or all of the audio routes prior to deleting the multicast flow.

A good rule of thumb is to use multicast when there are more than two receivers for a specific audio channel. You should also assume that the flow will flood throughout the entire network and therefore consume bandwidth on all network links.



Note: Certain Ethernet switches support IGMP (Internet Group Management Protocol), a protocol that provides the ability to "prune" multicast traffic so that it travels only to those end destinations that require that traffic. If this is the case and IGMP is correctly configured on all the Ethernet switches then multicast audio will not flood throughout the network but instead be sent only over the links needs to deliver it to subscribed devices.

Presets

Dante Controller supports loading and saving of audio routing configurations, known as Presets. A Preset file contains subscription, labeling and multicast flow configuration for a set of devices.

Saving Presets

To save a Preset, click the 'Save Preset' icon  in the toolbar of the Network View.

Alternatively select **File > Save Preset** via the Network view menu bar.

A 'Save a Preset File' dialog window is opened allowing the user to select a directory and filename for the Presets file to be created.

Routing view filtering may be used to restrict the extent of preset file generation. A preset contains the following information:

- Subscriptions for all receive channels that are displayed in the main routing view window
- Labels for all transmit channels that are displayed in the main Routing View window
- Multicast flow configuration for all devices that are displayed in either the transmit or receive area of the routing view

Loading Presets




Note: When loading Presets It is important to make sure that there is no filtering applied in the Routing View window.

Click on the 'Load Preset' icon  on the toolbar of the Network View, or select **File > Load Preset** via the Network view menu bar to bring up the "Open a Preset File" dialog window.

This allows the user to navigate to the directory where previously saved Preset files are stored, and select a Preset file to load.

Choose the preset file to load and click OK. This pops up a Preset Load window similar to that shown in the following screenshot:



Devices that will have their audio routing changed as a result of applying this preset are highlighted in green. Devices that are present in the Preset but are currently not on the network are highlighted in red italic. Devices and channels that will not be affected by this Preset are displayed in grey.

The expanded device view displays the subscription changes that would apply to this device. New subscriptions, labels and multicast flows are displayed in green, while existing elements that will be deleted are displayed as struck out text. Subscriptions that will be changed show the new subscription in green and the old subscription in struck out text.

Click the **OK** button to apply the preset or the **Cancel** button to cancel.

Troubleshooting

Messages on Startup

Error Message	Meaning & Actions
The Bonjour service is not available, please try again in a few minutes. If this message persists, please re-install the Bonjour software available from: http://www.apple.com/support/downloads/bonjourforwindows.html	<p>Affects: Windows only.</p> <p>Meaning: On some computers, system services may take a long time to start when the computer is rebooted and you may be able to log in and open the Dante Controller application before all required services are available.</p> <p>Action: If you have already installed Bonjour, please wait a few minutes to allow the services to start and try again. The Dante Controller application should then start normally.</p>
Dante Controller was unable to connect to the Common manager. Dante Controller cannot function without this connection. This problem is most likely caused by the Common manager service or daemon stopping unexpectedly. You may need to restart your computer or reinstall Dante Controller to repair this problem.	<p>Affects: Windows only.</p> <p>Meaning: Dante Control and Monitoring service is not responding.</p> <p>Action: Reboot your PC, or restart this service via Control Panel > Administrative Services > Services.</p>

Computer Configuration Checklist

Before installing Dante Controller, a computer needs to have:

- Bonjour installed (automatic for Macs)
- The user logged in with administrator privileges

A computer for use on the Dante network should have:

- Dante Controller installed

A correct Dante network configuration for the computer should have:

- The correct network interface selected
- The correct IP addresses used

Third-party PC or Mac firewall configuration

- Standard Windows and Mac firewalls will be configured on installation.
- Third party firewalls will need to be manually configured.

If your PC or has a third-party firewall installed, please read the Dante Controller and Dante Virtual Sound-card User Guides for detailed information about firewall requirements and configuration.

Troubleshooting Dante IP Address Configuration

All devices in a Dante network, including Dante Virtual Soundcard, must be using IP addresses from the same network. When using Dante Virtual Soundcard or Dante Controller, your PC or Mac must be connected to the Primary Dante network, and must have a correct IP address.



Note: NEW in 3.1.0: If a device name is shown in red, it means Dante Controller has automatically detected an error condition. This will be either an IP address configuration issue, or the device has entered failsafe. Double-click the red device name to see more information.

Correct IP configuration

Dante hardware devices are set to obtain their IP address automatically from the network. They will either:

- Automatically assign themselves an address in the range 169.254.*.* (172.31.*.* for the secondary network if present), or
- Obtain an IP address from a DHCP server if it is present on the network

Dante Virtual Soundcard uses the IP address of the PC or Mac it is installed on. If the computer has more than one wired Ethernet network interface, it will use the IP address of the selected network interface.

Your PC or Mac TCP/IP network configuration set should be set to use "Obtain an IP address automatically". This way it will automatically acquire an Link Local automatic IP address in the same network as other Dante devices. If a DHCP server is present, the PC and Dante devices will all acquire their IP addresses via DHCP.

Possible IP network configuration mistakes

Possible network configuration errors are listed below. Dante Controller will try to automatically detect these. If detected the offending device will be displayed in red.

PC/Mac IP misconfigurations

- Accidentally having multiple network interfaces with addresses in the same subnet

General IP misconfigurations

- Accidentally having multiple DHCP servers on the same network

Unusual - for example someone may have a PC connected to the network with a DHCP server running that they're not aware of.

- Incorrectly configured static IP addresses

You shouldn't need to configure static IP addresses at all. If for some unusual reason you do, it must be in the same subnet as the rest of the network.

Redundant network misconfigurations

Setting up a redundant network is described in "[Redundancy](#)". There are a few ways of misconfiguring a redundant network. More than one of these can be present at the same time.

- Connecting the secondary interface of a Dante device to the primary network

Most commonly by either misunderstanding how redundancy works, and using only one switch with all cables connected to it; or correctly using two switches or networks, but accidentally connecting one secondary cable to a primary network switch

- Joining the primary and secondary Dante networks

By connecting primary and secondary switches, or perhaps just using one switch.

- Multiple interfaces on the same device using the same IP address subnet

Possibly by having the same DHCP server on both primary and secondary networks, or both DHCP servers configured to serve the same IP addresses


What are the symptoms of using the wrong network interface on my PC or Mac?

If you have more than one wired network interface, and Dante Controller is not using the interface the rest of the Dante device are connected to:

- Dante Controller cannot see any Dante devices
- Dante Virtual Soundcard is not sending or receiving any audio when it is expected to

How do I check which network interface my Dante Controller/Dante Virtual Soundcard is using?

- The selected network interface can be viewed or changed via the 'interface selection' button  in the Network View toolbar of Dante Controller.



- It can also be viewed on the Dante Virtual Soundcard Settings tab
- If the Dante network is standalone and does not have a DHCP server installed, this address should be 169.254.*.*
- If the Dante network is using a DHCP server, the IP address should conform to the addressing scheme it is using (as shown in the image above)

How do I check IP addresses for all devices on my network?

- Use the Dante Controller Device Status tab to view the IP addresses of all the devices on your network.

Device Status						
Device Name	Type	Version	Primary Address	Primary Link Speed	Secondary Address	Secondary Link Speed
PCIe-060158	PCIe	3.4.11	10.12.0.220	1Gbps	Not Supported	Not Supported

- The Primary Address of all devices should follow the same IP address scheme (e.g. 169.254.*.* or 10.12.0.*). Same for secondary addresses...
- Note that some older Dante devices or devices running older firmware may not show this information.

Troubleshooting Switch Configuration and Cabling

Cables are the most vulnerable part of a network system. If you suspect cabling issues, check for:

- Faulty or manually terminated cables
- Unplugged /badly connected Ethernet cables
- Misconfigured switches
- Dante devices removed or turned off

Symptoms of switch or cabling issues

- You cannot see (some) devices in the Dante Controller network view
- Dante Controller shows orange “unsuccessful subscription” icons, which usually means a device that was present earlier is now missing
- Faulty cables can lead to intermittent faults, which may be heard as dropped samples or “cracks” in the audio
- Dante devices may appear and disappear in Dante Controller

Switch and Cabling Checklist

- Are all the connected link/status lights on the switch lit or flashing as expected?
 - Is the switch powered on?
 - Is the cable correctly plugged in at the switch and the PC or equipment?
- Is the switch correctly configured?
 - Perhaps QoS or VLANs have been incorrectly set up
- Are you using a switch from another application with an unchecked or tested configuration?
 - Consult the switch manual and check the switch configuration

Index

A

Audio Formats	18
Auto-configuration	15
Available Channels	34-35

B

Baseboard Tab	42
Bonjour	11, 47

C

Cabling	50
Cabling issues	50
Changing channel labels	35
Changing Tx channel labels	36
Channel	34
Clock Domains	29
Clock Master	28, 30
Clock Role	29
Clock Status View	28
Clock Synchronization	19, 37
Clock Types	19
Computer Configuration	47
Config Tab	39
Configure Dante Interfaces	21
Configuring Dante Controller	21
Common	47
Customizing the Network View	26

D

Dante Controller application	21
Dante Information	37
Dante Virtual Soundcard	20
Device	24, 33
Device Channels	26
Device Information	37
Device Name	27
Device Status View	26
Device View	31
DHCP	15, 31

Discovery	15
Display resolution	10
Downloading Dante Controller	12

E

Errors	31, 38
Events View	30
External Word Clock	29, 38

F

Failsafe	31
failsafe mode	31
File	24
Firewall Configuration	11
Firmware image	31
Firmware update	31
Flows	18
frame rate conversion	40
Frequency Offset	38

H

Help	24
------	----

I

Installing Dante Controller on Mac OSX	13
Installing Dante Controller on Windows	13
IP address	38
IP configuration	48

L

Labeling	15
Labels	15
Latency	20
Link Down	28
Load Preset	45

M

MAC address	38
Manufacturer	37
Memory	10
Messages	47
Monitoring	20
Multicast	17, 19, 33, 43

N

Network Interface	21
Network View	23

P

Passive	28
PDK	42
Platforms	10
Precision Time Protocol	19
Preferred Master	19, 29
Presets	45
Primary Address	27
Primary Interface	38
Primary Link Speed	27
Processor	10
Product Development Kit	42
Product Type	27
Product Version	27
PTP	19
PTP Slave	28
pull-up/down	40

R

Receive channels	26, 34
Receive Latency	40
Receive Tab	34
Redundancy	17
Redundant Networks	20
Refresh	33
Rename Device	39
Reset Device	40
Routing	16
Routing Audio	16
Routing View	25
Rx	26
Rx Utilization	38

S

Sample Rate	40
Saving Presets	45
Secondary Address	27
Secondary Interface	29, 39

Secondary Link Speed	27
Security Warning	13
Slave	19, 28
Slave to External Word Clock	19
Status	34, 38
Status Tab	36
Subscribing	35
Subscription status	17
Synchronization	19, 28
System Requirements	10

T

Transmit channels	26, 36
Transmit Flows	36
Transmit Tab	35
Troubleshooting	48, 50
Troubleshooting Switch Configuration	50
Tx	26
Tx Utilization	38

U

UDP	11
Unicast	17, 44
Uninstalling Previous Versions	12

W

Web Config	33
------------	----